**Smart Valve Positioner** TS700 Series **Instruction Manual** 





# tissin

Ver. PM-TS700EN-02/2022

# **Table of Contents**

| 1 | Intr | oduction 4  |  |  |  |  |  |  |
|---|------|---|--|--|--|--|--|--|
|   | 1.1  | General information for the user 4                        |  |  |  |  |  |  |
|   | 1.2  | Limited warranty and disclaimer 4                         |  |  |  |  |  |  |
|   | 1.3  | Requirement for safety 5                                  |  |  |  |  |  |  |
|   | 1.4  | Basic safety instructions for use in Ex area 6            |  |  |  |  |  |  |
|   |      | 1.4.1 Conditions to maintain intrinsically safety (Ex i)6 |  |  |  |  |  |  |
|   |      | 1.4.2 Intrinsically safety (Ex i) Certificate 6           |  |  |  |  |  |  |
| 2 | Pro  | duct Description 7  |  |  |  |  |  |  |
|   | 2.1  | Function 7  |  |  |  |  |  |  |
|   | 2.2  | Features 7  |  |  |  |  |  |  |
|   | 2.3  | Options 7   |  |  |  |  |  |  |
|   | 2.4  | Applications 7  |  |  |  |  |  |  |
|   | 2.5  | Label 8   |  |  |  |  |  |  |
|   | 2.6  | Product Code9   |  |  |  |  |  |  |
|   | 2.7  | Specification 10  |  |  |  |  |  |  |
|   | 2.8  | Structure 1   |  |  |  |  |  |  |
|   |      | 2.8.1 External structure 1                                |  |  |  |  |  |  |
|   |      | 2.8.2 Internal structure 12                               |  |  |  |  |  |  |
|   | 2.9  | System configuration 13                                   |  |  |  |  |  |  |
|   | 2.10 | Principle of operation 13                                 |  |  |  |  |  |  |
|   | 2.11 | Product Dimension 14                                      |  |  |  |  |  |  |
|   |      | 2.11.1 TS700 standard type 14                             |  |  |  |  |  |  |
|   |      | 2.11.2 TS700 with limit switch type 14                    |  |  |  |  |  |  |
|   |      | 2.11.3 TS700 feedback shaft connection 14                 |  |  |  |  |  |  |
| 3 | Inst | tallation15   |  |  |  |  |  |  |
|   | 3.1  | Before installation 15                                    |  |  |  |  |  |  |
|   | 3.2  | TS700L installation 15                                    |  |  |  |  |  |  |
|   |      | 3.2.1 Notes on installation 15                            |  |  |  |  |  |  |
|   |      | 3.2.2 Effective rotation angle range of feedback lever 16 |  |  |  |  |  |  |
|   |      | 3.2.3 Lever type and dimension 16                         |  |  |  |  |  |  |
|   |      | 3.2.4 Bracket Installation 17                             |  |  |  |  |  |  |
|   |      | 3.2.5 Dimension after installation 17                     |  |  |  |  |  |  |
|   | 3.3  | TS700R installation 18                                    |  |  |  |  |  |  |
|   |      | 3.3.1 TS700R installation examples 18                     |  |  |  |  |  |  |
|   |      | 3.3.2 TS700R bracket installation components 18           |  |  |  |  |  |  |
|   |      | 3.3.3 TS700R installation steps 19                        |  |  |  |  |  |  |
|   | 3.4  | TS720 Remote type installation 2'                         |  |  |  |  |  |  |
|   | 3.5  | Option module Installation 22                             |  |  |  |  |  |  |

|   |                          | 3.5.1 Position transmitter module(PTM) Installation   | 22   |  |  |  |  |
|---|--------------------------|---|--|--|--|--|--|
|   |                          | 3.5.2 HART communication module Installation  | 22   |  |  |  |  |
|   |                          | 3.5.3 Limit switch module Installation  | 23   |  |  |  |  |
|   |                          | 3.5.4 How to adjust limit switch cam  | 24   |  |  |  |  |
|   | 3.6                      | How to replace Air Filter   | 25   |  |  |  |  |
|   | 3.7                      | Orifice installation  | 26   |  |  |  |  |
| 4 | Pne                      | umatic connection   | 27   |  |  |  |  |
|   | 4.1                      | Air pressure condition  |  |  |  |  |  |
|   | 4.2                      | Pneumatic port Description  | 27   |  |  |  |  |
|   | 4.3                      | Air connection  | 28   |  |  |  |  |
|   |                          | 4.3.1 TS700L air connection   | 28   |  |  |  |  |
|   |                          | 4.3.2 TS700R air connection   | 28   |  |  |  |  |
| 5 | Ele                      | ctrical connection  | 29   |  |  |  |  |
|   | 5.1                      | Terminal description  | 29   |  |  |  |  |
|   | 5.2                      | Wiring diagrams   | 30   |  |  |  |  |
|   |                          | 5.2.1 Power and Feedback signal connection  | 30   |  |  |  |  |
|   |                          | 5.2.2 Mechanical Limit switch connection  | 30   |  |  |  |  |
|   |                          | 5.2.3 Proximity Limit switch connection   | 30   |  |  |  |  |
| 6 | Ca                       | bration   | 31   |  |  |  |  |
|   | 6.1                      | LCD description   | 31   |  |  |  |  |
|   | 6.2                      | Button description 32   |  |  |  |  |  |
|   | 6.2                      |   |  |  |  |  |  |
|   | 6.3                      | How to quickly perform Auto calibration   | 33   |  |  |  |  |
|   | 0.3                      | 6.3.1 Auto calibration Steps  | 33<br>33   |  |  |  |  |
|   | 6.4                      | 6.3.1 Auto calibration Steps Software map   |  |  |  |  |  |
|   |                          | 6.3.1 Auto calibration Steps  | 33   |  |  |  |  |
|   | 6.4                      | 6.3.1 Auto calibration Steps Software map   | 33<br>34   |  |  |  |  |
|   | 6.4<br>6.5               | 6.3.1 Auto calibration Steps<br>Software map<br>Main menu Description   | 33<br>34<br>35   |  |  |  |  |
|   | 6.4<br>6.5<br>6.6        | 6.3.1 Auto calibration Steps<br>Software map<br>Main menu Description<br>Main parameter menu Description  | 33<br>34<br>35<br>36   |  |  |  |  |
|   | 6.4<br>6.5<br>6.6        | 6.3.1 Auto calibration Steps<br>Software map<br>Main menu Description<br>Main parameter menu Description<br>Submenu Description   | 33<br>34<br>35<br>36<br>37   |  |  |  |  |
|   | 6.4<br>6.5<br>6.6        | <ul> <li>6.3.1 Auto calibration Steps</li></ul>   | <ul> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> </ul>   |  |  |  |  |
|   | 6.4<br>6.5<br>6.6        | <ul> <li>6.3.1 Auto calibration Steps</li> <li>Software map</li> <li>Main menu Description</li> <li>Main parameter menu Description</li> <li>Submenu Description</li> <li>6.7.1 TUNNING</li> <li>6.7.2 PARAMETR</li></ul> | <ul> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> <li>39</li> </ul>   |  |  |  |  |
|   | 6.4<br>6.5<br>6.6        | <ul> <li>6.3.1 Auto calibration Steps</li></ul>   | <ul> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> <li>39</li> <li>41</li> </ul>                                     |  |  |  |  |
|   | 6.4<br>6.5<br>6.6<br>6.7 | 6.3.1 Auto calibration Steps         Software map         Main menu Description         Main parameter menu Description         Submenu Description         6.7.1 TUNNING   | <ul> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> <li>39</li> <li>41</li> <li>44</li> </ul>                         |  |  |  |  |
| 7 | 6.4<br>6.5<br>6.6<br>6.7 | <ul> <li>6.3.1 Auto calibration Steps</li></ul>   | <ol> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> <li>39</li> <li>41</li> <li>44</li> <li>45</li> </ol>             |  |  |  |  |
| 7 | 6.4<br>6.5<br>6.6<br>6.7 | 6.3.1 Auto calibration Steps         Software map         Main menu Description         Main parameter menu Description         Submenu Description         6.7.1 TUNNING   | <ul> <li>33</li> <li>34</li> <li>35</li> <li>36</li> <li>37</li> <li>37</li> <li>39</li> <li>41</li> <li>44</li> <li>45</li> <li>48</li> </ul> |  |  |  |  |

# 1 Introduction

#### 1.1 General information for the user

This instruction includes installation, operation, maintenance, and parts information for Tissin TS700 Valve Positioner. Keep these instructions in a location which is easily accessible to every user and make these instructions available to every new owner of the device.

- Installation, commissioning and maintenance of the product can only be performed by trained specialist personnel who have been authorized by the plant operator to do so.
- Before installing or commissioning, be sure to read and thoroughly understand the product manual and operate the product properly.
- Operators must strictly observe the applicable national regulations with regards to installation, function tests, repairs, and maintenance of electrical products.
- Warnings and Cautions must be observed to prevent operator injury or damage to valve parts.

The manual can be altered or revised due to hardware of software upgrades without any prior notice. Please visit our website ( www.tissin.co.kr ) and check the latest documentation.

#### 1.2 Limited warranty and disclaimer

- This product has been fully inspected and shipped through a thorough quality inspection procedure. The manufacturer warranty period of the product is 18 months after the product is shipped from Tissin in Korea.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using under unqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

#### **1.3** Requirement for safety

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. These safety instructions are intended to prevent hazardous situations and/or equipment damage. For the safety, it is important to follow the instructions in the manual.

# 

Failure to observe the warning may result in serious injuries or death.

# 

Failure to observe this warning may result in damage to the device or personal injury.



Failure to observe the warning may result in damage to the device or may degrade performance.

- Only trained and authorized person should operate the machinery and the equipment.
- Do not use this positioner out of the range of its specifications as this can cause failure.
- Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
- Before loosening the pneumatic lines and valves, turn off the pressure and vent the pneumatic lines.
- Observe applicable accident prevention and the safety regulations for electrical equipment.
- Before handling the device or equipment, turn off the power supply and secure it from re-activation.

#### **1.4** Basic safety instructions for use in Ex area

To prevent the risk of explosion, observe not only the basic safety instructions in the respective operating instructions for operation in the Ex area, but also the following.

# 

- Observe the applicable safety regulations (also national safety regulations) as well as the general rules of technology for construction and operation.
- Make sure that the device is suitable for the area of use.
- Check the positioner's certified and permitted explosion proof range.

/!\

• Close all unnecessary Cable Gland with the locking screws approved by the explosion site.

#### **1.4.1** Conditions to maintain intrinsically safety (Ex i)

• Make sure to connect "Intrinsic safety" type protection device to intrinsically safe circuit only.

WARNING

- Observe the specifications for the electrical data on the certificate and in technical data.
- In order to maintain intrinsically safe protection, be sure to use a barrier that meets the following specifications.

| Barrier specifications   | Ui  | li    | Pi    | Ci    | Li   |
|--|-----|-------|-------|-------|------|
| Main power   | 28V | 101mA | 707mW | 0.6nF | 6uH  |
| Position transmitter,<br>Alarm1, Alarm2,<br>Limit Switch(Dry contact type) | 28V | 101mA | 707mW | 0.6nF | 6uH  |
| Limit Switch<br>(Proximity type)   | 16V | 26mA  | 34mW  | 30nF  | 50uH |

Note : Please refer to the relevant certificate for details.

#### 1.4.2 Intrinsically safety (Ex i) Certificate

Evaluation for the certificate is in progress now.

# 2 **Product Description**

#### 2.1 Function

Smart valve positioner TS700 series controls the valve stroke in response to an input signal of 4~20mA DC from the control panel, DCS or calibrator.

#### 2.2 Features

- Fail freeze function
- Zero air consumption when standby signal
- Prevents circuit board corrosion by external air exhaust design
- Built in air filter (5 micron) for protect PIEZO valve
- LCD and 4 button local control
- Quick and easy calibration
- PST and alarm function
- Built-in self-diagnostic function
- Strong vibration resistance and impact resistance

#### 2.2 Options

Optional functions can be added simply by installing modules.

- Position transmitter (4~20mA DC Feedback signal)
- HART communication (Ver. HART 7)
- Limit switch (Mechanical or Proximity type)
- Remote control type (TS720)

#### 2.4 Applications

TS700 is mounted on a pneumatic control valves and is used for fluid control of industrial parts.

- Oil and gas
- Chemicals
- Power plant
- Paper
- Water treatment
- Pharmaceutical
- Printing and dyeing processing
- Food and beverage
- Etc.

# 2.5 Label

| SMART POSITIONER  |                             |        |  |  |
|---|-----------------------------|--------|--|--|
| MODEL No.   | TS700LSn00000               | CE     |  |  |
| SERIAL No.  | 2201200                     |        |  |  |
| OPERATING TEMP.   | -25°C ~ +80°C               |        |  |  |
| EXPLOSION PROOF   | Non-Explosion Proof         |        |  |  |
| WEATHER PROOF   | IP66                        |        |  |  |
| INPUT SIGNAL  | 4~20mA DC                   |        |  |  |
| SUPPLY PRESSURE   | 0.14 ~ 0.7MPa (1.4 ~ 7 bar) |        |  |  |
| #397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea |                             |        |  |  |
| X   | Made in Korea               | tissin |  |  |

| Item                     | Description   |
|--------------------------|---|
| MODEL No.                | Indicate the model number.  |
| SERIAL No.               | Indicate the serial number.   |
| OPERATING TEMP.          | Indicate the allowable operating temperature.   |
| EXPLOSION PROOF          | Indicate the certified explosion proof grade.   |
| EXPLOSION PROOF<br>TEMP. | Indicate the ambient temperature range for the explosion proof.<br>This temperature range must be observed when using in<br>explosion-proof areas.          |
| WEATHER PROOF            | Indicate the enclosure grade.   |
| INPUT SIGNAL             | Indicates input current signal range.   |
| SUPPLY PRESSURE          | Indicate the allowable input supply pressure range.   |
| Ui, Ii, Pi, Ci, Li       | Indicate required barrier specification for intrinsically safety circuit configuration.<br>Please refer to the certificate for the detailed specifications. |

# 2.6 Product Code

| Model                   | TS700                       |        |        |        |       |   |   |   |   |   |
|-------------------------|-----------------------------|--------|--------|--------|-------|---|---|---|---|---|
| Standard type           | TS700                       |        |        |        |       |   |   |   |   |   |
| Remote type             | TS720                       |        |        |        |       |   |   |   |   |   |
| Stainless steel 316     | TS705                       |        |        |        |       |   |   |   |   |   |
| Motion type             | Linear                      | L      |        |        |       |   |   |   |   |   |
|                         | Rotary                      | R      | J      |        |       |   |   |   |   |   |
| Acting type             | Single                      |        | S      |        |       |   |   |   |   |   |
|                         | Double                      |        | D      |        |       |   |   |   |   |   |
| Explosion proof<br>type | Non-explosion proc          | of     |        | Ν      |       |   |   |   |   |   |
|                         | ATEX & IECEx<br>CCC & NEPSI |        |        | A<br>C |       |   |   |   |   |   |
|                         | KCs                         |        |        | K      |       |   |   |   |   |   |
| Connection type         |                             | Air co | nnect  | tion   | 1     |   |   |   |   |   |
|                         | G(PF)1/2                    | PT1    | /4     |        | 1     |   |   |   |   |   |
|                         | G(PF)1/2                    | NPT    |        |        | 2     |   |   |   |   |   |
|                         | NPT1/2                      | NPT    |        |        | 3     |   |   |   |   |   |
|                         | M20                         | NPT    | 1/4    |        | 4     |   |   |   |   |   |
|                         | M20                         | G1/-   | 4      |        | 5     |   |   |   |   |   |
| Lever (Linear type)     | 10~80mm                     |        |        |        |       | 1 |   |   |   |   |
|                         | 70~150mm                    |        |        |        |       | 2 |   |   |   |   |
|                         | Adapter type (30mn          |        |        |        |       | 3 |   |   |   |   |
|                         | Adapter type (70mn          |        |        |        |       | 4 |   |   |   |   |
| Lever (Rotary type)     | M6 x 39L (Fork leve         | r type | e)     |        |       | 1 |   |   |   |   |
|                         | NAMUR type                  |        |        |        |       | 5 |   |   |   |   |
| Ambient Temp.           | -25~80℃                     |        |        |        |       |   | S |   |   |   |
|                         | -40~80°C                    |        |        |        |       |   | L |   |   |   |
| Communication           | None                        |        |        |        |       |   |   | 0 |   |   |
|                         | 4-20mA Position tra         | nsmit  | ter    |        |       |   |   | 1 |   |   |
|                         | HART                        |        |        |        |       |   |   | 2 |   |   |
|                         | HART with 4-20mA            | Positi | on tr  | ansm   | itter |   |   | 3 |   |   |
| Limit switch            | None                        |        |        |        |       |   |   |   | 0 |   |
| (For TS700              | Mechanical type             |        |        |        | М     |   |   |   |   |   |
| & TS705)                | Proximity type              |        |        |        | Ρ     |   |   |   |   |   |
|                         | With dome cover (w          | vithou | ıt Lim | nit sw | itch) |   |   |   | D |   |
| Cable length            | 5m                          |        |        |        | 1     |   |   |   |   |   |
| (For TS720)             | 10m                         |        |        |        | 2     |   |   |   |   |   |
|                         | User define (Less th        | an 20  | m)     |        |       |   |   |   | Х |   |
| Fail Position           | Fail Freeze type            |        |        |        |       | F |   |   |   |   |
|                         | Fail Safe type              |        |        |        |       |   |   |   |   | S |

# 2.7 Specification

| Model            |                          | TS700                         | TS705                               |  |  |
|------------------|--------------------------|-------------------------------|-------------------------------------|--|--|
| Input sign       | al                       | 4~20mA DC                     |                                     |  |  |
| Impedanc         | ce                       | 500Ω (20mA DC)                |                                     |  |  |
| Supply pr        | essure                   | 0.15~0                        | ).8MPa                              |  |  |
| Stroke           |                          | 10~150mm(Linear typ           | e), 0~90º(Rotary type)              |  |  |
| Air conne        | ction                    | PT1/4, NP                     | PT1/4, G1/4                         |  |  |
| Gauge co         | onnection                | PT1/8,                        | NPT1/8                              |  |  |
| Conduit          |                          | G1/2, NP                      | T1/2, M20                           |  |  |
| Explosion        | proof type               | In progr                      | ress now                            |  |  |
| Enclosure        | 9                        | IP                            | 66                                  |  |  |
|                  | Acting Temp.             |                               | (Standard type),<br>(Low temp type) |  |  |
| Ambient<br>Temp. | Explosion proof<br>Temp. | In progress now               |                                     |  |  |
|                  | LCD operating<br>Temp.   | <b>-30</b> °C ∼ +85 °C        |                                     |  |  |
| Linearity        |                          | ±0.5% F.S.                    |                                     |  |  |
| Sensitivity      | /                        | ±0.2% F.S                     |                                     |  |  |
| Hysteresis       | s                        | ±0.5% F.S                     |                                     |  |  |
| Repeatab         | oility                   | ±0.3% F.S                     |                                     |  |  |
| Air consu        | mption                   | Below 0.01 LPM (Sup.=0.15MPa) |                                     |  |  |
| Required         | air quality              | Class 4 (ISO8573-1)           |                                     |  |  |
| Flow capa        | acity                    | Over 75 LPM (Sup.=0.15MPa)    |                                     |  |  |
| Material         |                          | Aluminum die cast             | Stainless steel 316                 |  |  |
| Weight           |                          | 1.6 kg                        | 4.0 kg                              |  |  |


## **Option specification**

| Option               | Item                 | Specification                         |  |
|----------------------|----------------------|---------------------------------------|--|
| HART                 | HART version         | HART 7                                |  |
| Position transmitter | Wire connection type | 2 Wires                               |  |
| Position transmitter | Supply voltage       | 10~30V DC                             |  |
| Limit switch         | Mechanical type      | OMRON D2F-LA<br>AC125V, 3A, DC30V, 2A |  |
|                      | Proximity type       | P+F NJ1,5-F-N<br>DC8.2V 8.2A          |  |

Note: Please contact our sales department for other specifications.

#### 2.8 Structure


#### 2.8.1 External structure



- ① Dome cover
- ② External ground bolt
- 3 Feedback lever
- (4) Conduit
- (5) Vent filter
- 6 Air supply filter
- ⑦ Power terminal block
- (8) Limit switch
- 9 Pressure gauge
- 10 Supply port
- ① OUT1 port
- 2 OUT2 port
- 13 Button
- 14 LCD
- (15) Dome indicator
- Imit switch terminal block

**Note: (b)** Dome indicator is only mounted on the product with limit switch option.

#### 2.8.2 Internal structure




- ① PIEZO valve
- 2 Button
- ③ Position transmitter module (Option)
- ④ PCB cover
- (5) Limit switch (Option)
- 6 Limit switch terminal block
- ⑦ Power terminal block

- (8) Feedback terminal block (Option)
- 9 Main PCB
- 10 HART module (option)
- ① Potentiometer


#### 2.9 System configuration

Basically, the control valve system consists of a positioner for controlling the pneumatic pressure of the actuator, an actuator for controlling the opening of the valve, and a valve for controlling the flow of the fluid.




#### 2.10 Principle of operation

TS700 receives 4-20mA input signal of the control room, micro-processor (CPU) compares input signal with position feedback through potentiometer and sends control signal to I/P conversion module torque motor, torque motor converts it to a pneumatic signal to controls PIEZO valve to controls the opening of the control valve by converting output pressure of OUT1 and OUT2.




# 2.11 Product Dimension


#### 2.11.1 TS700 standard type



## 2.11.2 TS700 with limit switch type



#### 2.11.3 TS700 feedback shaft



# 3 Installation

#### 3.1 Before installation

#### 

- Make sure if TS700 is appropriate to the valve and actuator installation conditions and the site requirements specifications before installation.
- If the installation state is not correct, TS700 control characteristics may be degraded.

#### 3.2 TS700L installation


#### 3.2.1 Notes on installation

When make the mounting bracket and connecting the lever to the stem connection pin, be sure to observe the following two points.

If failure to observe the followings, it will affect the product performance such as linearity.

#### 

- ① When the valve stroke is 50%, the feedback lever should be horizontal.
- ② When the valve stroke is 50%, the stem connection pin must be located at the numeric position marked on the feedback lever that is corresponding to the valve stroke.



- ① Feedback lever
- ② Stem connection pin
- ③ Pin fixing spring

- ④ Actuator stem
- 5 Valve opening indicator


#### 3.2.2 Effective rotation angle range of feedback lever

The effective rotation angle of TS700L lever is respectively 30° upward and downward that is based on horizon.

Follow 3.2.1 notes, effective rotation angle can be maintained to achieve the best performance.



- If the rotation angle range is too small during operation, the performance of products such as linearity may be degradation.
- If the rotation angle range is too big during operation, may damage the product or cause malfunctions.




#### 3.2.3 Lever type and dimension

The numeric positions marked on the feedback lever correspond to the valve stroke, and the stem connection pin must be connected to the corresponding marked location.


| Lever No. | Valve stroke                                    | Dimensions |
|-----------|---|------------|
| No.1      | 10~80mm   |            |
| No.2      | 70~150mm  |            |
| No.3      | 10~30mm<br>(For the tube less<br>type actuator) |            |
| No.4      | 10~70mm<br>(For the tube less<br>type actuator) |            |

#### 3.2.4 Bracket Installation

Refer to the TS700L drawing (refer to 2.11.1) and actuator drawing, please make appropriate bracket and install the positioner on the actuator.



#### 3.2.5 Dimension after installation




- $\textcircled{1} \quad \text{Stem connection pin} \\$
- ② Feedback lever
- ③ Bracket

- ④ Actuator york
- (5) Lever adapter

#### 3.3 **TS700R** installation

#### 3.3.1 Rotary type installation examples




<Fork lever type>

<NAMUR type>

#### 3.3.2 Rotary type bracket installation components

Components No.1~9 are provided with the brackets.

The brackets support the NAMUR mounting standard (VDI/VDE3835, IEC60534-6-2).





<Fork lever type>

- Lower bracket(2)
- ② Upper bracket(1)
- ③ M6 nut(4)
- ④ Spring washer (4)
- (5) M6\*15 bolt (4)

- 6 Fork lever type shaft lever(1)
- ⑦ NAMUR shaft adapter (1)
- M4 bolt(2) 8
- 9 M6\*15 bolt(4)

#### 3.3.3 TS700R installation steps





#### 3.4 TS720 Remote type installation


TS720 is designed cable to the sensor part and the main body, it is designed to transmit the change of the stem position of the valve to the body through the potentiometer built in the sensor.

#### **Application site**

- Where the valve is located at high or inaccessible location.
- High temperature environment where is over than 85°C. (Non-explosion proof type only) (Maximume ambient temperature of the sensor part is 100°C)
- Large vibrating lines.

#### Installation

- ① Install Sensor part on the valve, and install Body part on the accessible place.
- ② Please follow the installation instructions of TS700L or TS700R for Sensor part's installation.
- ③ Sensor part and Body part are connected by the cable. (the length of cable must not over than 20m)
- ④ OUT port of Body part should connect to the actuator using Pneumatic pipe.



#### 3.5 Option module Installation


According to the site requirements, the following modules can be purchased separately and installed.

#### 

- Please shut off the power supply and install the modules.
- Please connect (5) Jumper when you install PTM.
- Please disconnect ⑤ Jumper when you install HART module or install HART and PTM both.


#### 3.5.1 Position transmitter module(PTM) Installation

- ① Open the body cover and PCB cover, and install PTM to Main PCB as figure below.
- ② Please set feedback zero point settings and end point settings again after installed PTM. Please refer to page38 <OUT ZERO> and <OUT END> setting method.




#### 3.5.2 HART communication module Installation

Open the body cover and PCB cover, and install HART module to Main PCB as figure below.




#### 3.5.3 Limit switch module Installation

There are two types of limit switch module, mechanical and proximity type.




<Mechanical type module>



<Proximity type module>

#### Installation steps


- ① Open the cover.
- 2 Install the limit switch module to PCB protective cover groove and fix it with fixing bolts.
- ③ Turn the camshaft and install it to the main shaft.
- ④ Fix the camshaft with fixing bolts.
- (5) Install the dome indicator to the camshaft.



#### Note


Standard product does not have a dome indicator window, so the cover also be replaced when you add limit switch module to the product.

#### 3.5.4 How to adjust limit switch cam



The cam position is set at the factory. If you want to change the cam position, please follow the steps below.


- ① Open the cover and disassemble the dome indicator by referring to the above figure.
- 2 Loosen the fixing bolt slightly with a Phillips screwdriver, but do not disassemble it.
- 3 Adjust cam 3 and 4 by referring to the figure below, and adjust the angle so that the switch operates at the position you want.
- ④ After adjusting the angle, fasten the fixing bolt tightly.



#### How to replace Air filter 3.6


# **CAUTION**

- •
- Be careful when replacing the air filter as the valve may move. Please shut off the air pressure supplied to the positioner and replace the filter. •



| Purpose           | It protects internal PIEZO valve by removing foreign substances contained in the air supplied to the positioner.  |  |  |  |
|-------------------|---|--|--|--|
| How to<br>replace | <ol> <li>Loosen the fixing bolt with a flat-blade driver.</li> <li>Take out the inner filter, replace it, and fix it again with fixing bolt.</li> <li>When replacing the filter, please install O-ring well as shown in the picture above.</li> </ol>   |  |  |  |
| Note              | <ul> <li>Please check the filter periodically depending on the situation and replace it if necessary.</li> <li>If foreign matter adheres to the filter due to long-term use, it may affect the control performance of the product.</li> <li>Air filters can be reused by cleaning, but please replace the filter in case of oil contamination.</li> </ul> |  |  |  |

#### 3.7 Orifice installation




#### Purpose

A normal action product does not need to install the orifice, but if the hunting phenomenon occurs after installation on a small actuator, it can be solved by installing an orifice to reduce the output flow of air pressure transmitted to the actuator from the positioner. The hole size of the orifice is 1mm.

#### How to install

As figure below, Install the orifice into OUT1 port, and fix it by turning it all the way with a flatbladed screwdriver.

- When using for single type actuator, please install orifice to OUT1 port only.
- When using for double type actuator, please install orifice to both OUT1 and OUT2 ports.




Note : Please contact us, if you need the above parts.

# 4 **Pneumatic connection**

# 4.1 Air pressure condition

- Use only dehumidified and dust-extracted compressed clean air.
- The air pressure input must be equipped with a regulator to supply constant air pressure.


## 4.2 Pneumatic port Description




#### 4.3 Air connection

• This product is designed to increase the air pressure of OUT1 as 4 ~ 20mA current input signal increases.

#### 4.3.1 TS700L air connection



#### 4.3.2 TS700R air connection





# 5 Electrical connection

# 

- Check that the input current is within the product specification range. Exceeding the rating might cause a malfunction to circuit boards or burn out electrical components.
- Check polarity of + and exactly and connect wires.
- Separate the input current cable and the feedback signal cable correctly. Connecting the feedback signal cable to Power terminal for a long time may damage the main board.

#### 5.1 Terminal description






- Input signal (+)
- ② Input signal (-)
- ③ Internal ground
- ④ Feedback signal (+)
- 5 Feedback signal (-)


- 6 External ground bolt
- ⑦ Conduit

## 5.2 Wiring diagram


#### 5.2.1 Power and feedback signal connection



#### 5.2.2 Mechanical Limit switch connection




#### 5.2.3 Proximity Limit switch connection




# 6 Calibration

# 6.1 LCD description



| No.  | Displayed contents    | Description   |   |  |  |
|------|-----------------------|---|---|--|--|
| 1    | Menu information      | Displays the running menu.<br>(Main menu, Main parameter, Sub parameter)                        |   |  |  |
| 2    | Menu value            | Displays t  | he present menu or parameter value.         |  |  |
| 3    | Menu value unit       | Displays t  | he present menu's value unit.               |  |  |
|      |                       | PV  | Progress value                              |  |  |
| 4    | Menu value<br>symbol  | SV  | Signal value                                |  |  |
|      | - Symbol              | MV  | Motor control value                         |  |  |
| 5    | Progress bar          | Displays the progress of the processor in bar form.   |   |  |  |
| 6    | Main parameter        | Displays the currently selected main parameter.   |   |  |  |
| 7    | Parameter bar         | Displays t  | he position of the selected main parameter. |  |  |
| 8    | HART<br>communication | The icon is displayed when HART communication is in progress.                                   |   |  |  |
| 9    | Error code            | The icon is displayed if there is an error during calibration or operation.                     |   |  |  |
| 10   | Save                  | The icon is displayed when changing the internal setting values such as parameter modification. |   |  |  |
| (11) | LOCK                  | The icon is displayed when the program is locked.   |   |  |  |
| 12   | UNLOCK                | The icon is   | s displayed when the program is unlocked.   |  |  |

# 6.2 Button description



| Button     | Function  | Description  |  |  |
|------------|-----------|--|--|--|
| ENTER      | confirm   | <ul><li>Execute the functions of the selected menu.</li><li>Save the modified parameter values.</li></ul>  |  |  |
| ESC        | cancel    | <ul> <li>Move from the current menu to the upper level menu.</li> <li>Cancel the current command.</li> </ul>   |  |  |
| UP move up |           | <ul> <li>Move between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change the set value of the selected parameter to a larger value</li> </ul> |  |  |
| DOWN       | move down | <ul> <li>Move between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change the set value of the selected parameter to a small value</li> </ul>  |  |  |

#### 6.3 How to quickly perform Auto calibration

Open the cover of product and follow below steps to perform Auto calibration quickly.

- ① Please input current signal **18mA**, then press **<UP>** button for 3 seconds.
- ② The positioner automatically performs Auto calibration.
- ③ Auto Calibration is performed sequentially from STEP 1 to 7 on LCD, and may take 2-5 minutes depending on the valve size.

| $\mathbb{A}$ | NOTICE |
|--------------|--------|
|--------------|--------|

• If an error occurs during Auto calibration, please refer to Error codes on page 49 to 50.

#### 6.3.1 Auto calibration Steps

When you progress auto calibration, it automatically proceed in the following steps below.

| Steps | Description  |
|-------|--|
| STEP0 | Check ZERO point of the valve speed.<br>Check the reference point of valve stop.   |
| STEP1 | <b>Find ZERO point of the valve stroke.</b><br>The valve position after all the pneumatic pressure of actuator chamber connected to OUT1 port is exhausted is recognized as ZERO point.  |
| STEP2 | <b>Find END point of the valve stroke.</b><br>The valve position after the regulator setting pressure is supplied to actuator chamber connected to OUT1 port is recognized as END point. |
| STEP3 | Check the valve fully close time.<br>Measure the time of the valve takes from full open to full close.   |
| STEP4 | Check the valve fully open time.<br>Measure the time of the valve takes from full close to full open.  |
| STEP5 | <b>Check the minimum valve movement</b><br>Measure the motor signal reference value, when the position of valve<br>at 25%.   |
| STEP6 | <b>Check the minimum valve movement</b><br>Measure the motor signal reference value, when the position of valve<br>at 50%.   |
| STEP7 | <b>Check the minimum valve movement</b><br>Measure the motor signal reference value, when the position of valve<br>at 75%.   |

#### 6.4 Software map

- To enter Main Parameter menu : Please input 4-20mA current signal and press **<ENTER>** button for 3 seconds after booting up.
- To enter Submenu : Press **<UP>** or **<DOWN>** button to select Main Parameter menu and press **<ENTER>** button.
- To select Submenu : Press **<UP>** or **<DOWN>** button.

| Main<br>parameter<br>menu | TUNNING  | PARAMETR | DEVICE P | INFOMATN | DIAGNOST | EMERGNCy |
|---------------------------|----------|----------|----------|----------|----------|----------|
|                           | AUTO RUN | DEAD bND | ACTU SNG | FIRM VER | ERR CODE | PASSWORD |
|                           | AM FULL  | MIMLO LO | ACTU LIN | DEVI REV | AUTO CHK | EMGY NON |
|                           | ACT NORM | MINHI OP | FORCE OP | HART VER | PST RUN  | FULL OP  |
|                           | VAL OPCL | MINHI CL | FORCE CL | dEid     | PST CFG  | FULL CL  |
|                           | VAL ZERO | CONST OP | DAMP     | POLL ADD | PST REDy | STOP     |
| 6 J                       | VAL END  | CONST CL | SPLT ZER | TRAVEL K |          | UNLOCK   |
| Submenu                   | OUT ZERO | CHAR LIN | SPLT END | OP TIME  |          |          |
|                           | OUT END  | USER DEF | COMPENSA | CL TIME  |          |          |
|                           | IN ZERO  |          | ACT NORM |          |          |          |
|                           | IN END   |          | OUT NORM |          |          |          |
|                           | OUTP ZER |          | HT NORM  |          |          |          |
|                           | OUTP END |          | DSP NORM |          |          |          |

#### 6.5 Main menu description

After the product is booted, **<MAIN LIN>** is displayed, which shows the current opening of the valve. Press **<UP>** or **<DOWN>** button to move to the following menu and check the corresponding information.

In Main menu, information such as the valve opening and the magnitude of the input current signal can be checked and the execution of the command or the modification of the parameter value cannot be performed.

| Main menu  | Description  |                        |  |
|------------|--|------------------------|--|
|            | Display the percentage of current valve opening value.<br>Depending on the set value of the flow characteristics, one of the<br>following values is displayed.   |                        |  |
|            | LCD display value  | Flow characteristics   |  |
| MAIN LIN   | MAIN LIN   | Linear                 |  |
|            | MAIN EQ1   | EQ1 (1/25)             |  |
|            | MAIN EQ2   | EQ2 (1/50)             |  |
|            | MAIN QO  | Quick Open             |  |
|            | MAIN USR   | User defined 17 points |  |
| MAIN IN %  | <ul> <li>Display the magnitude of input signal that the positioner recognizes as percentage.</li> <li>If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply.</li> <li>If the supply current is normal, please reset <in zero=""> and <in end=""> settings in <tuning> of main parameter.</tuning></in></in></li> </ul> |                        |  |
| MAIN IN mA | <ul> <li>Display the magnitude of input signal that the positioner recognizes as mA.</li> <li>If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply.</li> <li>If the supply current is normal, please reset <in zero=""> and <in end=""> settings in <tunning> of main parameter.</tunning></in></in></li> </ul>       |                        |  |
| MAIN VEL   | <ul> <li>Display currently operating speed of the valve as numbers.</li> <li>As the value, between -2047 to +2048, negative numbers indicate speed at close, and positive numbers indicate speed at open.</li> <li>0 means stop and the larger the absolute value, the faster the speed.</li> </ul>  |                        |  |
| MAIN DEV % | <ul><li>Display the percentage of error between the current input signal and valve opening value.</li><li>The larger the error, the lower the control characteristic.</li></ul>  |                        |  |
| MAIN TEM   | Display the current ambient temperature.   |                        |  |
| MAIN KPR   | Display the pressure level of the pneumatic pressure output to<br>OUT1 port.<br>It is displayed only on product equipped with an optional pressure<br>sensor.  |                        |  |

## 6.6 Main parameter menu Description

Main parameter menu corresponds to main menu in which various parameters are classified by function.

- After the product is booted, press **<ENTER>** button for 3 seconds to enter Main Parameter menu.
- Main parameter menu is classified as below and can be moved by pressing <UP> or
   **OOWN>** button.
- Press **<ENTER>** button in the corresponding menu to enter Submenu.

| Main parameter<br>menu | Main function  |  |  |  |
|------------------------|--|--|--|--|
| TUNNING                | <ul> <li>Run Auto calibration.</li> <li>Change Zero and Span of the valve manually.</li> <li>Change Zero and Span of feedback signal manually.</li> </ul>  |  |  |  |
| PARAMETR               | <ul> <li>Set Dead band.</li> <li>Change PID values.</li> <li>Change flow characteristics.</li> </ul>   |  |  |  |
| DEVICE P               | <ul> <li>Set Single/Double according to actuator type.</li> <li>Set Linear/Rotary according to actuator type.</li> <li>Set signal point of Force Open/Close.</li> <li>Set acting type. (Direct Action / Reverse Action)</li> <li>Set the valve acting speed. (DAMP)</li> </ul> |  |  |  |
| INFOMATN               | <ul> <li>Display the product model.</li> <li>Display the device and HART version.</li> <li>Display Full Open/Close time.</li> <li>Display the current ambient temperature, the recorded maximum ambient temperature, and the recorded minimum ambient temperature.</li> </ul>  |  |  |  |
| DIAGNOST               | <ul> <li>Display the error code.</li> <li>Auto check function.</li> <li>Set PST function.</li> </ul>   |  |  |  |
| EMERGNCy               | <ul> <li>Set Password.</li> <li>In case of emergency, set function to forcibly open the valve, or close valve, or maintain current position.</li> <li>Set Lock and Unlock function.</li> </ul>   |  |  |  |

#### **Submenu Description** 6.7

The following is a detailed description of Main parameter menu's Submenu.

- Press <**ENTER**> button in Main parameter menu to enter Submenu. Use <**UP**> and <**DOWN**> button to move between Submenu. ٠
- •

#### 6.7.1 TUNNING

| Submenu  |  | Description  |  |  |
|----------|--|--|--|--|
| AUTO RUN | <ul> <li>Run Auto calibration.</li> <li>Executable from any input signal between 4 and 20 mA.</li> <li>It takes 1~3 minutes, depending on the valve size.</li> </ul>   |  |  |  |
|          | Select Auto calibrat   | tion mode.   |  |  |
|          | Mode   | Description  |  |  |
|          | AM FULL  | Set all parameter values again.  |  |  |
| АМ       | AM WDTH  | Reset MIMLO OP and MINHI CL values(which are PIEZO control characteristic parameters).   |  |  |
|          | AM OPCL  | Reset CONST OP and CONST CL values(which are PIEZO control characteristic parameters).   |  |  |
|          | AM ZEb R   | Only reset End point and Zero point of the valve, but the other parameter values are not modified.                             |  |  |
|          | Factory setting  | AM FULL  |  |  |
|          |  | nsitivity of product.<br>I value can be changed when hunting occurs due to a<br>on of the valve stem or a small actuator size. |  |  |
|          | Mode   | Description  |  |  |
| ACT NORM | ACT NORM   | Normal setting   |  |  |
|          | ACT LAGR   | Select when actuator size is too big   |  |  |
|          | ACT FRIC   | Select when the valve friction is too big  |  |  |
|          | Factory setting  | ACT NORM   |  |  |
| VAL OPCL |  | current signal, it performs the function of opening<br>/e with < <b>UP</b> > or < <b>DOWN</b> > button manually.               |  |  |
| VAL ZERO | Reset ZERO point of the valve manually.<br>Input 4mA current, press <b><up></up></b> and <b><down></down></b> button to change the<br>valve position, and press <b><enter></enter></b> button to save the current valve<br>position, then the positioner recognizes the current position as valve<br>ZERO point.                                   |  |  |  |
| VAL END  | Reset END point of the valve manually.<br>Input 20mA current, press <b><up< b="">&gt; and <b><down< b="">&gt; button to change the<br/>valve position, and press <b><enter< b="">&gt;button to save the current valve<br/>position, then the positioner recognizes the current position as valve<br/>END point.</enter<></b></down<></b></up<></b> |  |  |  |

| OUT ZERO | Reset ZERO point of the feedback signal manually.<br>Input <b>4mA</b> current signal, valve reaches Zero position, after press<br><b><up></up></b> or <b><down></down></b> button to adjust the value, until the 4mA feedback<br>signal is output, and then press <b><enter></enter></b> button to save. |
|----------|--|
|          |  |
|          | Please reset <b>OUT ZERO</b> setting after installing feedback module.   |
| OUT END  | Reset END point of the feedback signal manually.<br>Input <b>20mA</b> current signal, valve reaches end position, after press<br>< <b>UP</b> > or < <b>DOWN</b> > button to adjust the value, until the 20mA<br>feedback signal is output, and then press < <b>ENTER</b> > button to save.               |
|          |  |
|          | Please reset <b>OUT END</b> setting after installing feedback module.  |
| IN ZERO  | Reset ZERO value of input signal manually.<br>If < <b>MAIN IN%</b> > and < <b>MAIN mA</b> > displayed at Main menu differ from<br>the actual input signal, conduct the commands of this menu.<br>Input 4mA current at this menu and press < <b>ENTER</b> > button twice to<br>save.                      |
|          |  |
|          | After replacing the main board or conduct program initialization, please reset <b>IN ZERO</b> setting.   |
| IN END   | Reset END value of input signal manually.<br>If < <b>MAIN IN%&gt;</b> and < <b>MAIN mA</b> > displayed in Main menu differ from<br>the actual input signal, conduct the commands of this menu.<br>Input <b>20mA</b> current at this menu and press < <b>ENTER</b> > button twice to<br>save.             |
|          |  |
|          | After replacing the main board or conduct program initialization, please reset <b>IN END</b> setting.  |
| OUTP ZER | Reset ZERO value of the pressure sensor manually.<br>At Zero point of the valve, press < <b>UP</b> > or < <b>DOWN</b> > button to adjust<br>the output pressure value, and press < <b>ENTER</b> > button to save.  |
| OURP END | Reset END value of the pressure sensor manually.<br>At END point of the valve, press < <b>UP</b> > or < <b>DOWN</b> > button to adjust<br>the output pressure value, and press < <b>ENTER</b> > button to save.  |

## 6.7.2 PARAMETR

| Submenu  | Description  |  |  |  |
|----------|--|--|--|--|
| DEAD bND | <ul> <li>Dead band range, the range of allowable control error.</li> <li>If hunting or oscillation occurs due to high packing friction of the valve, the problem can be solved by increasing the value within the range allowed by the field.</li> <li>If the value is set too high, the accuracy may be reduced.</li> </ul>   |  |  |  |
|          | Range  | 0~10%  |  |  |
|          | Factory setting  | 0.3%   |  |  |
| MIMLO LO | positioner finds the target  | blve hunting or oscillation problem but<br>point slowly.<br>itioner finds the target point quickly but it is |  |  |
|          | Range  | 1~500  |  |  |
| MINHI OP | <ul> <li>Display ON time of PIEZO valve output current when the valve open.</li> <li>If increase the time, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation.</li> <li>If reduce the time, can solve hunting or oscillation problem but positione finds the target point slowly.</li> </ul>   |  |  |  |
|          | Range  | 1~500  |  |  |
| MINHI CL | <ul> <li>Display ON time of PIEZO valve output current when the valve close.</li> <li>If increase the time, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation.</li> <li>If reduce the time, can solve hunting or oscillation problem but positioner finds the target point slowly.</li> </ul>   |  |  |  |
|          | Range  | 1~500  |  |  |
| CONST OP | <ul> <li>Display the proportional constant value of PIEZO valve output current to reach the target point when the valve open.</li> <li>If increase the value, can solve hunting or oscillation problem but positioner finds the target point slowly.</li> <li>If reduce the value, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation.</li> </ul>  |  |  |  |
|          | Range  | 0.1~5.0  |  |  |
| CONST CL | <ul> <li>Display the proportional constant value of PIEZO valve output current to reach the target point when the valve close.</li> <li>If increase the value, can solve hunting or oscillation problem but positioner finds the target point slowly.</li> <li>If reduce the value, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation.</li> </ul> |  |  |  |
|          | Range 0.1~5.0  |  |  |  |

|          | Set the characteristics of the valve control.   |   |                                 |               |            |            |           |             |
|----------|---|---|---------------------------------|---------------|------------|------------|-----------|-------------|
|          | 100   |   | Input<br>(mA)                   | Linear<br>(%) | EQ1<br>(%) | EQ2<br>(%) | QO<br>(%) | USER<br>(%) |
|          |   |   | 4                               | 0             | 0          | 0          | 0         | 0           |
|          | 80<br>80<br>80<br>000000000000000000000000000   |   | 5                               | 6.25          | 2.55       | 1.31       | 29.13     | 4           |
|          | × open.   |   | 6                               | 12.5          | 3.26       | 2.81       | 46.84     | 8           |
|          | %) 60 Quict Use   | 9/  | 7                               | 18.75         | 4.16       | 4.54       | 57.21     | 12          |
|          | STR   | Lineot  | 8                               | 25            | 5.32       | 6.55       | 64.56     | 18          |
|          | 40  |   | 9                               | 31.25         | 6.79       | 8.92       | 70.27     | 30          |
|          |   | EQ. Pr. D. Pr. 150                                    | 10                              | 37.5          | 8.67       | 11.73      | 74.93     | 40          |
|          | 20  | ¥/40 <sup>4</sup>                                     | 11                              | 43.75         | 11.07      | 14.76      | 78.87     | 50          |
|          |   |   | 12                              | 50            | 14.14      | 18.26      | 82.28     | 59          |
|          | 0 4 8 12  | 2 16 20   | 13                              | 56.25         | 18.06      | 22.58      | 85.29     | 65          |
|          |   | put (mA)  | 14                              | 62.5          | 23.06      | 27.93      | 87.99     | 70          |
|          |   |   | 15                              | 68.75         | 29.45      | 34.55      | 90.42     | 75          |
| CHAR LIN |   |   | 16                              | 75            | 37.61      | 42.73      | 92.65     | 80          |
|          |   |   | 17                              | 81.25         | 48.02      | 52.85      | 94.69     | 85          |
|          |   |   | 18                              | 87.5          | 61.32      | 65.37      | 96.59     | 90          |
|          |   |   | 19                              | 93.75         | 78.31      | 80.85      | 98.35     | 95          |
|          |   |   | 20                              | 100           | 100        | 100        | 100       | 100         |
|          |   | CHAR LIN  | Linea                           | r             |            |            |           |             |
|          |   | CHAR EQ1 Equal percentage (1/25)                      |                                 |               |            |            |           |             |
|          | Mode  | CHAR EQ2 Equal percentage (1/50)                      |                                 |               |            |            |           |             |
|          |   | CHAR QUI  | CHAR QUI Quick Open             |               |            |            |           |             |
|          |   | CHAR USR  | CHAR USR User defined 17 points |               |            |            |           |             |
|          | Factory setting   | CHAR LIN  |                                 |               |            |            |           |             |
|          | <ul> <li>Run the special flow curve by user-defined 17 points.</li> <li>In addition to the above Linear, Equal percentage, Quick open and oth typical flow characteristics, the user can set the 4~20mA correspondin valve stroke position to achieve special flow curve control.</li> <li>To run this function, <char usr=""> must be set at <char> menu.</char></char></li> </ul> |   |                                 | onding        |            |            |           |             |
|          | Steps   | Description   |                                 |               |            |            |           |             |
| USER DEF | *USR P0   | Set the valve position when the input signal is 4 mA. |                                 |               |            | A.         |           |             |
|          | *USE P1   | Set the valve po                                      | sition v                        | when th       | ne inpu    | t signal   | is 5 m    | A.          |
|          | *USR P2   | Set the valve po                                      | sition                          | when th       | ne inpu    | t signa    | is 6 m    | A.          |
|          | *USR P3~16  | Follow above sta<br>input signal is 7-                | •                               | -             | , the va   | lve pos    | sition w  | hen the     |
|          | <b>Solution</b> input signal is 7~19mA . <b>*USR P17</b> Set the valve position when the input signal is 20 mA.   |   |                                 |               |            |            |           |             |

#### 6.7.3 DEVICE P

| Submanu  | Description   |                                      |                                    |  |  |
|----------|---|--------------------------------------|------------------------------------|--|--|
| Submenu  |   |                                      |                                    |  |  |
|          | Depending on the actuator type, it should be set to Single or Double manually.  |                                      |                                    |  |  |
|          |   |                                      | E                                  |  |  |
| ACTU SNG | If the setting differs from the actuator type, the control characteristic may be degraded.  |                                      |                                    |  |  |
|          |   | ACTU SNG                             | Single type                        |  |  |
|          | Mode  | ACTU DbL                             | Double type                        |  |  |
|          | Factor and the  | TS700L                               | ACTU SNG                           |  |  |
|          | Factory setting   | TS700R                               | ACTU DbL                           |  |  |
|          | Depending on the actuator type, it should be set to Linear or Rotary manually.  |                                      |                                    |  |  |
|          |   |                                      | E                                  |  |  |
| ACTU LIN | If the setting differs f be degraded.   | rom the actuator typ                 | be, the control characteristic may |  |  |
|          |   | ACTU LIN                             | Linear type                        |  |  |
|          | Mode  | ACTU ROT                             | Rotary type                        |  |  |
|          |   | TS700L                               | ACTU LIN                           |  |  |
|          | Factory setting   | TS700R                               | ACTU ROT                           |  |  |
|          | When the input signal is higher than the set value, the value is forced to open. This parameter is used to move the value into its seat with the maximum force of the actuator. |                                      |                                    |  |  |
|          | Valve Stroke %  |                                      |                                    |  |  |
|          | 100   |                                      |                                    |  |  |
| FORCE OP |   | Force open set<br>Force close set po | Input Signal %                     |  |  |
|          | Range   | 0~100%                               |                                    |  |  |
|          | Factory setting   | TS700L<br>TS700R                     | <u> </u>                           |  |  |
|          | Noto  |                                      | value set to 100%, this function   |  |  |
|          | Note is not applied.  |                                      |                                    |  |  |

|           | <ul> <li>When the input current signal is lower than the set value, the valve is forced to close.</li> <li>When the valve is closed, residual pressure in the actuator chamber can be completely released.</li> </ul>  |  |  |  |  |
|-----------|--|--|--|--|--|
| FORCE CL  | Range  | 0~100%   |  |  |  |
|           | Factory setting  | 0.3%   |  |  |  |
|           | Note   | When the value set to 0%, this function is   |  |  |  |
| DAMP      | The higher the set value value.  | not applied.<br>operating speed of the valve.<br>ue, the slower the operating speed of the<br>ting problem in small actuator can be solved.<br>0~500   |  |  |  |
|           | Factory setting  | 0  |  |  |  |
|           | Note   | When the value set to 0, this function is not applied.   |  |  |  |
| SPLIT ZER | value during the split range<br>For example, if the set valu<br>50%, 12mA corresponds to<br>of the valve opening as sho<br>on the right figure .   | ue is 00%  |  |  |  |
|           | Dange  | 0<br>12mA<br>Input Signal (mA)   |  |  |  |
|           | Range<br>Factory setting   | 0<br>12mA<br>Input Signal (mA)<br>0~100.0%   |  |  |  |
| SPLIT END | Range         Factory setting         Set End point of the signal value during the split range         For example, if the set valu         50%, 12mA corresponds to of the valve opening as sho on the right figure . | 0<br>12mA<br>12mA<br>12mA<br>100<br>0~100.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0%<br>0.0% |  |  |  |
|           | Factory setting<br>Set End point of the signal<br>value during the split range<br>For example, if the set valu<br>50%, 12mA corresponds to<br>of the valve opening as sho  | 0<br>12mA<br>Input Signal (mA)<br>0~100.0%<br>0.0%<br>0.0%<br>0 control.<br>100<br>100<br>0 control.<br>100<br>0 control.<br>100<br>100<br>0 control.<br>100<br>100<br>100<br>100<br>100<br>100<br>100<br>10   |  |  |  |

\_\_\_\_\_

|          | 1   |                      |   |                        |  |
|----------|---|----------------------|---|------------------------|--|
|          | This parameter corrects the error between LCD value and actual valve opening.                                     |                      |   |                        |  |
|          | NOTICE  |                      |   |                        |  |
| COMPENSA | This function should only be used with Linear type products and Rotary products must be set to 0%.                |                      |   |                        |  |
|          | Range -50.0~50.0%   |                      | 0.0%  |                        |  |
|          | Factory setting   |                      | Linear type)                                      | 3.0%                   |  |
|          |   |                      | 00R(Rotary type) 0.0%                             |                        |  |
|          | Change the action mode  | of the valve.        |   |                        |  |
|          | Reverse Actio   | n                    | Dii   | rect Action            |  |
| ACT NORM | Valve Stroke%   |                      | Valve Stroke%                                     |                        |  |
|          | 0 4mA 20m   | Input Signal mA<br>A | 0 20mA  | Input Signal m/<br>4mA |  |
|          | Mode  | ACT NORI             | <b>V</b> Rever                                    | se Action              |  |
|          |   | ACT REVE             | Direct Action                                     |                        |  |
|          | Factory setting   | ACT NORI             | N   |                        |  |
|          | Change the output mode of feedback signal to the same percentage as the valve stroke, or the opposite percentage. |                      |   |                        |  |
|          | Normal  |                      |   | Reverse                |  |
| OUT NORM | 100<br>(%)<br>0<br>4mA<br>0<br>4mA<br>20mA<br>20mA<br>Output Signal (mA)  |                      | 100<br>(%)<br>0<br>20mA 4mA<br>Output Signal (mA) |                        |  |
|          | Mode  | OUT NOR              | <b>V</b> Nor                                      | rmal action            |  |
|          |   |                      | OUT REVE Reverse action                           |                        |  |
|          | Factory setting OUT NORI  |                      | Μ   |                        |  |
|          | Change the display mode HART communication.   | e of the valve       | e opening trans                                   | smitted through        |  |
| HT NORMR | Mode  | HT NORM              | HT NORMR Direct action                            |                        |  |
|          |   | HT REVER             | Rev   | verse action           |  |
|          | Factory setting   | HT NORM              | R   |                        |  |

|          | Change the display mode of the valve opening on LCD. |  |  |  |
|----------|--|--|--|--|
|          | Mode Description                                     |  |  |  |
|          | DSP NORM   | Displayed 0% on LCD when the valve is 0%, and  |  |  |
| DSP NORM |  | displayed 100% on LCD when the valve is 100%.  |  |  |
|          | DSP REVE   | Displayed 100% on LCD when the valve is 0%, an |  |  |
|          |  | displayed 0% on LCD when the valve is 100%.    |  |  |
|          | Factory setting                                      | DSP NORM                                       |  |  |

## 6.7.4 INFOMATN

You can find the following information through Submenu.

| Submenu  | Description   |  |  |
|----------|---|--|--|
| FIRM VER | Display firmware version of the product.  |  |  |
| DEVI REV | Display the version of device.  |  |  |
| HART VER | Display the version of HART communication.  |  |  |
| dEid     | Display HART Device ID number   |  |  |
| POLL ADD | Display Polling address of the device in HART communication.  |  |  |
| TRAVEL K | Display the accumulated total travel distance of the valve after the positioner has been used. (Unit: K%)<br>One full travel distance from full close to full open means 100% = 0.001K% For example, if the travel value is 1K%, this means that the valve has moved 1000 stroke percentages. |  |  |
| OP TIME  | Display the time that takes from the valve fully close to fully open during<br>Auto calibration.<br>Unit : Second   |  |  |
| CL TIME  | Display the time that takes from the valve fully open to fully close during<br>Auto calibration.<br>Unit : Second   |  |  |

### 6.7.5 DIAGNOST

| Submenu  | Description   |  |  |
|--|---|--|--|
| ERR CODE   | Display error code of the product.<br>You can check the error code to resolve the problem.<br>For details, please refer to Page 51. |  |  |
|  |   | ction checks the installation status of the product, internal ube connection, etc.   |  |
|  | Error code  | Description  |  |
|  | PNEUMATIC   | No pneumatic output to OUT port.   |  |
|  | POTENMTR  | Main shaft gear and Potentiometer gear are dislocated due to external shocks, etc.   |  |
| SIZE ANGLE Installation<br>product. Installatio |   | Display rotation angle of the lever of the product.<br>Installation problems do not occur frequently for Rotary<br>product. However, for linear product, the angle of the<br>product may be bigger or less than the effective<br>angle(60°) depending on bracket and the position of<br>lever connection. If displayed number is less than 40°,<br>please refer to page 15-17 to correctly install the<br>product again. |  |
|  | COMPENSATE  | Display the optimal compensation value based on the current rotation angle.  |  |
|  | Run PST function  | n according to the following PST CFG configuration.  |  |
| PST RUN affecting to<br>What is PST? stem from according to  |   | Partial stroke testing (or PST), within the range of not<br>affecting to the flow process, PST prevents the valve<br>stem from sticking by moving the valve finely<br>according to the set value and the period. In case of<br>emergency, it can make the valve operate normally.  |  |
| PST CFG  | Set necessary iter<br>Submenu of PST  |  |  |

\_

|          |                     | 1   |   |  |  |
|----------|---------------------|---|---|--|--|
|          | Submenu             |   | Description   |  |  |
|          | 0P POINT            | Set the initial valve position for PST to start.<br>Valve initial position must be within ±1% from " <b>0S</b><br><b>POINT</b> ". If not, wait until this condition is satisfied. |   |  |  |
|          |                     | Default value   | 100%  |  |  |
|          |                     | Range   | 0~100%  |  |  |
|          |                     | Set 1st target p  | position of PST.  |  |  |
|          | 1S POINT            | Default value   | 90%   |  |  |
|          |                     | Range   | 0~100%  |  |  |
|          |                     | Set 2nd target p  | position of PST.  |  |  |
|          | 2N POINT            | Default value   | 80%   |  |  |
|          |                     | Range   | 0~100%  |  |  |
|          |                     | Set the waiting before the seco   | time after the first PST is end and ond PST start.  |  |  |
|          | INTERVAL            | Default value   | 20 (Seconds)  |  |  |
|          |                     | Range   | 1~100 (Seconds)   |  |  |
|          | LATENCY             | start.<br>After reaching the to the initial possible specified by the   | Set the waiting time from " <b>1S POINT</b> " to " <b>2N POINT</b> "<br>start.<br>After reaching the first target point " <b>1S POINT</b> ", return<br>to the initial position, wait for " <b>LATENCY</b> " time<br>specified by the user, and then move to the second<br>" <b>2S POINT</b> " target point again. |  |  |
|          |                     | Default value   | 10 (Seconds)  |  |  |
|          |                     | Range   | 1~100 (Seconds)   |  |  |
|          | LMT TIME            | If the time to rea  | lowed to reach the target point.<br>each the target value during the PST<br>eeds " <b>LMT TIME</b> " time or there is no<br>T is considered to have failed and PST<br>interrupted.  |  |  |
|          |                     | Default value   | 50 (Seconds)  |  |  |
|          |                     | Range   | 1~100 (Seconds)   |  |  |
|          |                     | In PST process, if the valve position exceeds<br>"EMERGNCY" set value, PST function is stopped.   |   |  |  |
|          | EMERGNCY            | Default value   | 15%   |  |  |
|          |                     | Range   | 0~100%  |  |  |
| PST REDy | The following infor | nction execution result value.<br>nformation is displayed on LCD based on the set values<br>tion results. See the table below to confirm PST executior<br>ion.                    |   |  |  |
|          |                     | PST REDy  | Ready to run PST.   |  |  |
|          | Result Value        | PST SUCS  | PST success.  |  |  |
|          |                     |   |   |  |  |

| PST TOUT | "LMT TIME" failed to reach the target value within the set time value range.      |
|----------|---|
| PST FIXD | Valve has no action.  |
| PST DOUT | Exceed the target value more than 1%.   |
| PST EMRG | When allowable range of valve<br>movement, i.e. "EMERGENCY" value<br>is exceeded. |

## 6.7.6 EMERGNCy

| Submenu  | Description   |   |                           |  |
|----------|---|---|---------------------------|--|
| DADOWODD | Must put a password to enter this menu.<br>The password is set at the factory and cannot be changed by the user.  |   |                           |  |
| PASSWORD | Factory setting   | Press <b>UP &gt; ENTER &gt; DOWN &gt; UP</b> button sequentially. (1321 on LCD) |                           |  |
|          | Set the position of the valve to be moved when an abnormality of the positioner is detected. (If priority value of error code is "0") (refer to page 51)                                |   |                           |  |
|          |   | EMGy NON  | Do not take any action.   |  |
| EMGY NON | Mada  | EMGy OP   | Open the valve fully.     |  |
|          | Mode  | EMGy CL   | Close the valve fully.    |  |
|          |   | EMGy STP  | Stop the valve operation. |  |
|          | Factory setting   | actory setting EMGy NON   |                           |  |
| FULL OP  | Open the valve fully by manual regardless of the input signal.  |   |                           |  |
| FULL CL  | Close the valve fully by manual regardless of the input signal.   |   |                           |  |
| STOP     | Maintain the present valve position regardless of the input signal.   |   |                           |  |
| UNLOCK   | It locks to prevent changing all parameter values.<br>When set to " <b>LOCK</b> ", all commands such as Auto calibration, PID changes, and parameter values settings cannot be changed. |   |                           |  |
|          | Mode  | LOCK  | Lock the program          |  |
|          |   | UNLOCK  | Unlock the program        |  |
|          | Factory setting   | UNLOCK  |                           |  |

# 7 Error code and Troubleshooting

# 7.1 Error code during Auto calibration

- Error code as below is displayed on LCD if an error occurs during Auto calibration.
- Check the error code and refer to the table below to solve the problem.

| No | Error Code | Cause   | Solution   |
|----|------------|---|--|
| 1  | STEP0 V0   | Displayed when the valve<br>does not stop after a long<br>period of time when the data<br>is measured to detect the<br>first stop of the valve during<br>auto calibration.<br>And it is mainly caused by<br>damage to Main board. | Replace Main PCB.  |
| 2  | STEP1 PZ   | Displayed when Zero point is lower than allowable range.  | <ul> <li>Check the status of the positioner installation or reinstall the positioner.</li> <li>Set initial angle (Zero point) of the lever higher than the current status.</li> </ul>  |
| 3  | STEP2 PE   | Displayed when End point is higher than allowable range.  | <ul> <li>Check the installation status of the positioner or reinstall the positioner.</li> <li>Set final angle (End point) of the lever lower than the current status.</li> </ul>  |
| 4  | ACT TYPE   | Displayed when Zero point<br>and End point of the lever<br>are too close or equal.  | <ul> <li>Check the status of supply air.</li> <li>Unplug the potentiometer cable in the positioner and reconnect it to Main board.</li> <li>Check the status of feedback lever installation. And set the operation angle that between initial angle(Zero point) and final angle(End point) over 40 degree.</li> <li>Replace Main PCB.</li> </ul> |
| 5  | STEP3 CT   | Displayed when Close time is too long during auto calibration.  | <ul> <li>Check the status of feedback<br/>lever installation.</li> <li>If Zero point of the valve changes,<br/>please conduct auto calibration<br/>2~3 times.</li> <li>If the actuator size is too big,<br/>please set ACT mode as ACT<br/>LAGR and conduct auto<br/>calibration again. (Refer to<br/>page37)</li> </ul>                         |

| 6 | STEP4 OT | Displayed when Open time is too long during auto calibration.                                    | • • | Check the status of feedback<br>lever installation.<br>If the actuator size is too big,<br>please set ACT value as ACT<br>LAGR and conduct auto<br>calibration again. (Refer to<br>page37)                      |
|---|----------|--|-----|---|
| 7 | STEP5 WD | Displayed when the<br>positioner can't find the<br>accurate position within the<br>allowed time. | • • | Check the status of feedback<br>lever installation.<br>If the actuator size is too big,<br>please set <b>ACT</b> value as <b>ACT</b><br><b>LAGR</b> and conduct auto<br>calibration again. (Refer to<br>page37) |
| 8 | DEAD ZNE | Displayed when the feedback value of potentiometer is out of allowed range.                      | •   | Check if the potentiometer is out<br>of zero adjustment with the gear<br>(vibration or external shock is the<br>cause).<br>Potentiometer is damaged.<br>(please replace the potentiometer)                      |
| 9 | ERR      | Displayed when auto<br>calibration failed due to other<br>unknown reasons.                       | •   | Replace the positioner.   |

# 7.2 Error code during operation

- If there is a problem during the operation, please enter "ERR CODE" which is Submenu of "DIAGNOST" to check the error code.
- Check the error code and refer to the table below to solve the problem.

| No | Code | priority | Cause  | Solution   |
|----|------|----------|--|--|
| 1  | L    | 1        | Valve End point is set too high  | <ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul> |
| 2  | к    | 1        | Valve Zero point is set too low  | <ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul> |
| 3  | J    | 1        | Valve End and Zero<br>points are set too<br>close. (Use angle is<br>too small) | <ul> <li>Increase the angle of use by<br/>repositioning the positioner closer to<br/>the actuator.</li> </ul>  |
| 4  | I    | 1        | Input current is<br>below 3.8mA  | Check input current signal   |
| 5  | н    | 1        | Input current is over 22mA   | Check input current signal   |
| 6  | G    | 1        | BIAS value<br>exceeds limit  | <ul> <li>Run Auto-Calibration again (Accuracy<br/>is significantly reduced when used<br/>without auto-calibration)</li> </ul>  |
| 7  | F    | 1        | Ambient<br>temperature is too<br>high  | Check ambient temperature  |
| 8  | Е    | 1        | Ambient<br>temperature is too<br>low   | Check ambient temperature  |
| 9  | D    | 1        | Used over 100,000 cycles   | Check positioner regularly   |
| 10 | С    | 0        | Used over 500,000<br>cycles  | Check positioner regularly   |
| 11 | В    | 0        | Used over 1million<br>cycles   | Replace positioner   |
| 12 | Α    | 0        | EEPROM is damaged  | Replace PCB  |



# Tissin Co.,Ltd.

201-1105, No 397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea 14449 Tel : +82-32-624-4573, Fax : +82-32-624-4574 **www.tissin.co.kr**